





01. WHAT'S IN THE BOX?



BIG DISPLAY / MULTIFUNCTION
 CLOCK & SPEAKER




02. OVERALL VIEW




1. Backward
2. "M" Mode (Dimmer)
3. Forward
4. Time set
5. Alarm 1
6. Alarm 2
7. Multifunction encoder: Play/pause, volume, answer calls
8. Power button
9. "AUX" - Auxiliary input
10. Micro USB charging port
11. Charging LED indicator
12. "TF" - TF card port

SCREEN DISPLAY FUNCTIONS




1. Hour, minute, second (year, month, day)
2. Date
3. Week
4. Alarm indicators 1 & 2
5. Daily alarm indicator
6. Bluetooth mode indicator
7. FM mode indicator
8. Auxiliary mode indicator
9. TF card mode indicator
10. Battery level indicator


CR-90BT




03. POWER ON / OFF




04. SETTING THE CLOCK / CANCEL SETTING




05. BATTERY AND CHARGING



06. RADIO FM




07. ALARM SETTING TWO DIFFERENT TIMES FOR THE ALARM



08. DISPLAY AND LIGHT




09. ALARM ON/OFF




* SHORT PRESS THE BUTTON TWICE

10. SNOOZE



11. SLEEP



* SHORT PRESS THE BUTTON TWICE

