

# aiwa®

Japan est1951

## SW-100



QUICK GUIDE **EN**

GUÍA RÁPIDA **ES**

GUIDE RAPIDE **FR**

KURZANLEITUNG **DE**

GUIDA RAPIDA **IT**

+16

### SMART WATCH

# aiwa®

Japan est1951

Follow us! aiwaEU



www.eu-aiwa.com


AIWA CO., LTD.  
Kita-Ku  
TOKYO 115-0045, JAPAN

©AIWA EUROPE S.L.  
All Rights Reserved.

Printed in P.R.C.



## 01. WHAT'S IN THE BOX?




## + aiwa




www.eu-aiwa.com

## 02. OVERALL VIEW



1. Screen
2. Button
3. Charging POGO PIN
4. Temperature sensor
5. Heart rate
6. Strap
7. Buckle


## FRONT VIEW - BACK VIEW




## 03. POWER ON



## 04. CHARGING



## 05. CHANGE THE STRAP



## 06. SCREEN. BASIC OPERATIONS

1. 6 different spheres to choose, press and hold the screen slide vertically to select your favorite, press to select
2. The watch automatically records your daily activities. Click to see more detailed data.
3. Press the icon and the watch will monitor your heart rate, swipe right to exit.
4. Press the sport function, select from 14 sport modes, the watch will automatically record your data. Swipe right to stop the exercise.
5. When you want to pause the movement or finish it slide to the right.
6. The interface will automatically display the day's sleep data, if you use it to sleep.
7. Unread messages will be displayed in the message interface.
8. Connect to the app and select the city in advanced settings.
9. Click on the icon and wait 30 seconds to get the result.
10. Click the alarm interface and you can view and modify the reminders you set. The clock will vibrate when it comes to a reminder.
11. Select blood oxygen, wait 30 seconds for the result.
12. Select the stopwatch, tap the start and pause keys, swipe right to exit.
13. Press the screen to turn on or off the sedentary reminder you set in the app.
14. The device can be used as a remote control for the camera function of your phone.
15. Tap the music function icon to enter the music playback control interface.
16. In the "settings" interface you will see more functions such as dial switch, **language**, reboot, power off, system, temperature settings, phone search, brightness and display off (time interval).

\* Language available: English, Spanish, Portuguese, Italian, German, Hungarian, Polish, French

## 07. LINK THE "OPLAYER SMART LIFE" APP TO YOUR SMARTWATCH

1. Turn on your smartphone's Bluetooth.
2. Open the OPLAYER SMART LIFE app.
3. Click Add a device to find your smartwatch (fig. 1).
4. Click on your smartwatch name in the list of scanned devices to link it.
5. Your smartphone will display a Bluetooth pairing request, accept to connect (fig. 2).
6. Once paired to the app, it accepts all permissions that are required on your smartphone, whether iOS or Android. Your SW-100 will be connected to your phone.




Fig 1



Fig 2

## 08. UNLINK YOUR DEVICE

### For Android systems

1. Tap Delete device with in the OPLAYER SMART LIFE App on your smartphone (fig. 3).

### For iOS systems

1. Tap Delete device with in the OPLAYER SMART LIFE App on your smartphone (fig. 3).
2. Go to my Bluetooth devices and select Forget Device as option in the following images.




Fig 3

### OPLAYER SMART LIFE



Android

iOS

